SONY

like.no.other™

| NW-A1200 B NEW | |
|---|---|
| General Data | |
| Maximum Battery Life (h) | 20 |
| Colour Variations | Violet / Black / Bleu / Pink |
| Material - Front | Polycarbonate |
| - Middle band | Zinc |
| - Back | Aluminium |
| Memory | |
| Memory Type | Hard disk |
| Memory Size | 8 GB |
| Supplied Accessories | |
| Connect Player | • |
| Cradle (recording And Charging) | (optional) |
| Usb Cable | • |
| Headphones | • |
| Headphone Extension Cord | • |
| Battery | built-in |
| Ac Power Adapter (usb Connection Type) | • |
| Carrying Pouch | (optional) |
| Network Function | |
| High Transfer Speed | • (Hi-Speed USB aka USB 2.0) |
| Usb Connection | • |
| Audio Out (line Out / Headphone) | • / • |
| Pc Data Storage | • |
| Selectable Data Compression (atrac3/atrac3plus) | • |
| Mp3 Direct Playback Compatible | • |
| Data Conversion From Mp3/wma/wav To Atrac3 Or Atrac3plus | • |
| Cddb Automatic Music Information | • |
| Music Information Editting On Pc | • |
| Walkman Control On Pc | • |
| Supported Audio Formats | |
| Atrac3 | 66 / 105 / 132 kbps |
| Atrac3plus | 48 / 64 / 96 / 128 / 160 / |
| | 192 / 256 / 320 / 352 kbps |
| Mp3 | 32 kbps - 320 kbps |
| Wma (non-drm) | 32 kbps - 320 kbps |
| Wma (drm) | - |
| Playback | |
| Group Function Operation | playlist |
| Repeat (1/all/shuffle/group) | • / • / • / • |
| Artist Link | • |
| Shuffle (normal/my Favourite/time Machine/artist Link/sports) | • / • / • / – / – |
| Bookmark | • |
| 6 Band Equalizer | • |
| Avls | • |
| Hold | • |
| Display | |
| Dot Matrix Organic El Display | • |
| Language Support | EN / FR / DE / ES / IT |
| Battery | |
| Supplied Battery | Lithium-ion |
| Charging Time (H) | 2H (80% via AC), |
| | 3H (100% via AC), |
| | 7h (100% via USB) |
| Dimensions & Weight | |
| Dimensions W x H x D (mm) | 55.0 x 88.1 x 18.7 |
| Weight g (excl./incl. batt.) | 109 |
| Accessories | |
| Connect Player Software | • |
| Compatible with Sonic Stage software | • |
| Cradle (recording And Charging) | (optional) |
| Usb Cable | • |
| Headphones | • |
| Headphone Extension Cord | • |
| Battery | built-in |
| Clip | – |
| Ac Power Adapter (usb Connection Type) | • |